




| N° | ERP       | Part name                     | N° | ERP        | Part name                            |
|----|-----------|-------------------------------|----|------------|--------------------------------------|
| 1  | 109060056 | Top cover                     | 34 | 136020119  | Cable passing hole                   |
| 2  | 109060053 | Service panel                 | 35 | 109060017  | Back grill                           |
| 3  | 103000335 | Evaporator                    | 36 | 109060051  | Top frame                            |
| 4  | 109060052 | Pillar                        | 37 | /          | /                                    |
| 5  | 109060023 | Fan panel                     | 38 | 119000058  | EEV                                  |
| 6  | 117110020 | Ambient temp. sensor T5-TH1   | 39 | 121000037  | 4 way valve coil                     |
| 7  | 132000015 | Fan blade                     | 40 | 121000034  | 4 way valve                          |
| 8  | 112000031 | Fan motor                     | 41 | 117110004  | Evaporator temperature sensor T3-TH2 |
| 9  | 109060027 | Fan motor bracket             | 42 | 113060188  | 4-way valve to evaporator piping     |
| 10 | 109060058 | Left panel                    | 43 | 1121000304 | High pressure switch                 |
| 11 | 109060042 | Service panel                 | 44 | 113020623  | Discharge pipe                       |
| 12 | 133470001 | Front panel                   | 45 | 113020579  | Gas return piping                    |
| 13 | 117020293 | Controller                    | 46 | /          | Seal tube                            |
| 14 | 109060054 | Pillar                        | 47 | 1121000464 | Low pressure switch                  |
| 15 | 109060004 | Evaporator support panel      | 48 | 113080123  | EEV to distribution piping           |
| 16 | 142000142 | Evaporator heating resistor   | 49 | 113030214  | 4-way valve to exchanger             |
| 17 | 109060050 | Base tray                     | 50 | 113070067  | Exchanger to EEV                     |
| 18 | 109060059 | Isolation panel               | 51 | 108010025  | Exchanger temperature sensor clip    |
| 19 | 117230003 | Reactor                       | 52 | 117110011  | Water outlet temp. sensor T2-TH5     |
| 20 | 101000188 | Compressor                    | 53 | 136010072  | Rubber ring on water flow switch     |
| 21 | 142000072 | Compressor heating resistor   | 54 | 1121000213 | Water flow switch                    |
| 22 | 113190007 | Sensor clip                   | 55 | 133020007  | PVC cover                            |
| 23 | 113190001 | Sensor holder                 | 56 | 133020012  | Red rubber ring                      |
| 24 | 117110021 | Discharge temp. sensor T6-TH3 | 57 | 102050004  | Water connection sets                |
| 25 | 109060044 | Service panel                 | 58 | 133020012  | Red rubber ring                      |
| 26 | 109060057 | Right panel                   | 59 | 102041126  | Titanium heat exchanger              |
| 27 | 108960058 | Terminal board                | 60 | 117110012  | Water inlet temp. sensor T1-TH6      |
| 28 | 115000004 | Power terminal                | 61 | 109060007  | Electric box cover                   |
| 29 | 136010004 | Clip                          | 62 | 117100046  | PCB                                  |
| 30 | 124020011 | Screw                         | 63 | 109060039  | Electric box                         |
| 31 | 106000012 | Pressure gauge                | 64 | 117240002  | Magnet ring                          |
| 32 | 109060055 | Back panel                    | 65 | 117240003  | Magnet ring                          |
| 33 | 110000039 | Cable connector               | 66 | 117020327  | TUYA 5GHz Wifi module                |